

User manual

Smart 4 turbo



Some services and apps may not be available in all countries. Please ask in-store for details.

Android is a trademark of Google Inc. The Android robot is reproduced or modified from work created and shared by Google and used according to terms described in the Creative Commons 3.0 Attribution Licence.


© Vodafone Group 2014. Vodafone and the Vodafone logos are trade marks of Vodafone Group. Any product or company names mentioned herein may be the trade marks of their respective owners.

| | |
|---|----|
| 1. Your mobile | 1 |
| 1.1 Removing the back cover | 1 |
| 1.2 Charging the battery | 2 |
| 1.3 SIM card and microSD card | 2 |
| 1.4 Powering on/off, Reboot and Aeroplane mode | 3 |
| 1.5 Locking/unlocking the screen | 3 |
| 1.6 Home screen | 4 |
| 1.7 Using the touchscreen | 5 |
| 1.8 Using the hard keys | 5 |
| 1.9 Notification and status icons | 6 |
| 1.10 Notification panel | 7 |
| 1.11 Managing applications | 8 |
| 1.12 Managing Home screen | 8 |
| 1.13 Managing folders | 9 |
| 2. Phone calls | 9 |
| 2.1 Making a call | 10 |
| 2.2 Answering or rejecting a call | 10 |
| 2.3 During a call | 11 |
| 2.4 Conference calls | 11 |
| 2.5 Answering another incoming call | 12 |
| 2.6 Supplementary services | 12 |
| 2.7 Voicemail | 13 |
| 3. People | 13 |
| 3.1 Adding a contact | 13 |
| 3.2 Quick Contact | 14 |
| 3.3 Managing contacts | 14 |
| 3.4 Managing groups | 15 |
| 3.5 Importing contacts from SIM card or storage | 16 |
| 4. Text input methods | 17 |
| 4.1 Using the text input panel | 17 |
| 4.2 Switching input methods | 17 |
| 4.3 Editing text | 17 |
| 4.4 Horizontal keyboard | 18 |
| 4.5 Input method settings | 18 |
| 5. Message+ | 19 |
| 5.1 Verify number | 19 |
| 5.2 Start a message | 19 |
| 5.3 Start a group chat | 20 |
| 5.4 Settings | 20 |


| | |
|--|----|
| 6. Messaging | 20 |
| 6.1 Creating a message | 20 |
| 6.2 Replying to a message | 21 |
| 6.3 Searching messages | 21 |
| 6.4 Deleting a message | 21 |
| 6.5 Customising message settings | 21 |
| 7. Email | 21 |
| 7.1 Adding an email account | 21 |
| 7.2 Switching accounts | 22 |
| 7.3 Combined account view | 22 |
| 7.4 Viewing emails | 22 |
| 7.5 Creating and sending emails | 22 |
| 7.6 Replying to and forwarding emails | 23 |
| 7.7 Saving email attachments | 23 |
| 7.8 Deleting an email account | 23 |
| 7.9 Customising email account settings | 23 |
| 8. Data service | 24 |
| 8.1 Turning on the data service | 24 |
| 8.2 Wi-Fi | 24 |
| 8.3 Sharing your phone's data connection | 26 |
| 8.4 Bluetooth | 28 |
| 9. Browser | 29 |
| 9.1 Browsing web pages | 29 |
| 9.2 Managing bookmarks | 30 |
| 9.3 Setting a home page | 30 |
| 9.4 Customising browser settings | 30 |
| 10. Camera and video camera | 31 |
| 10.1 Taking a photo | 31 |
| 10.2 Recording a video | 32 |
| 10.3 Panoramic mode | 32 |
| 11. Gallery | 33 |
| 11.1 Viewing pictures and videos | 33 |
| 11.2 Editing a picture | 33 |
| 12. Google Play™ Music | 34 |
| 12.1 Adding music to a playlist | 35 |
| 12.2 Playing a playlist | 35 |
| 12.3 Playing a music file | 35 |
| 13. Accounts and syncing | 36 |

| | |
|--|-----------|
| 13.1 Adding an account | 36 |
| 13.2 Enabling syncing | 36 |
| 14. More applications | 37 |
| 14.1 Calendar | 37 |
| 14.2 Alarm clock | 38 |
| 14.3 Calculator | 39 |
| 15. Settings | 39 |
| 15.1 Setting the date and time | 39 |
| 15.2 Setting the display | 39 |
| 15.3 Adjusting the volume | 40 |
| 15.4 Changing the phone ringtone | 41 |
| 15.5 Managing applications | 41 |
| 15.6 Security settings | 42 |
| 16. NFC | 43 |
| 17. Location access | 44 |
| 18. Restoring factory settings | 45 |
| 19. FOTA (Firmware Over The Air) updating | 45 |
| Frequently Asked Questions | 47 |
| Product Safety Information | 50 |
| Technical data | 67 |
| Accessories | 68 |

1. Your mobile



1.1 Removing the back cover



Removing the back cover: Hold the sides of the phone securely; use a thumbnail to lift up the back cover from the notch.

Removing the battery: Hold the sides of the phone securely and lift up the battery from the slot notch.

Note: Make sure that you turn off the phone before replacing or removing the battery.

1.2 Charging the battery


1. Connect the small end of the supplied USB charging/data cable to your phone, using the Micro USB port at the top.
2. Connect the other end to the supplied plug and insert that into a mains socket to start charging your phone.
3. The power LED will glow green when battery level is more than 90%.

Hints:

- You can also charge your phone, though more slowly, using the powered USB ports on your computer.
- You can view the battery information by touching the battery icon in the quick access panel.
- The phone will power off automatically when the battery is too low. Charge the battery if this happens. When the battery is critically low, the charging status may not be displayed immediately (you must wait before it is displayed). Using the phone to play games or perform other activities during the charging process may cause the phone to power off due to low battery.
- The battery will gradually discharge if is left for a long period of time. Before using the battery again, you must recharge it in order to power on and use your phone as normal.

1.3 SIM card and microSD card

Insert the SIM card and the microSD card as shown in the images below.



Notes:

- Take care to keep the SIM card safe. Do not bend it, damage it, or allow it come into contact with static electricity or water.
- The SIM card must be inserted correctly according to the markings on the case.
- Make sure that your SIM card is a micro SIM (3FF) type.
- This phone does not support hot swapping. Unplug the data cable and power off the phone before inserting or removing the SIM card and microSD card.

1.4 Powering on/off, Reboot and Aeroplane mode

Power on: When the phone is off, press and hold the Power key to turn on the phone.


Power off: When the phone is on, press and hold the Power key until the options pop up. Select Power off and then OK to turn off the phone.




Reboot: When the phone is on, press and hold the Power key until the options pop up. Select Reboot to reboot the phone.

Aeroplane mode: When the phone is on, press and hold the Power key until the options pop up. Select Aeroplane mode and the phone will automatically disable all signal transmission.

1.5 Locking/unlocking the screen


Locking the phone turns the screen off and stops any unwanted button presses. To lock the screen while using the phone, simply press the Power key.

To unlock it, press the Power key, drag  to the right, you can also drag it in other directions.

Note: Touch  >  > Security > Screen lock to set the type of lock screen. You can also find  on the right-most Home screen.

1.6 Home screen



1. Status bar: Displays notifications and status icons. Gently slide down to open the Notification panel.
2. Display area: The main display area of the phone.
3. Touch  to open the applications list.
4. Shortcut bar: Touch to enter the corresponding application.

Hints:

1. Swipe your finger left or right to access other home screen panels.
2. Go to Settings > Display, mark the Home screen checkbox to enable the home screen looping function.

1.7 Using the touchscreen

Touch: Launch applications and other functions.

Touch and hold: Touch and hold the screen for 2 or more seconds to open the control options for the current screen.


Slide/swipe: Slide the screen up, down, left and right to view information, applications, web pages, etc.


Drag: Touch and hold the selected application and drag it to another location.


Pinch/spread: Place two fingers on the screen and draw them apart to zoom in or together to zoom out.

Rotate: Automatically change the screen orientation from portrait to landscape by turning the phone sideways.
































1.8 Using the hard keys

 (Back key): Touch the back key to view the screen for the previous operation.

 (Home key): Touch the home key to view the homescreen. Press and hold the home key to open Google Now™.


 (Menu key): Touch the menu key to display or hide the menu of applications. Press and hold the menu key to view the multiple applications.

1.9 Notification and status icons


| | | | |
|--|---|---|------------------------------------|
|  | No signal |  | No network |
|  | Signal strength |  | Aeroplane mode |
|  | 4G in use |  | HSPAP in use |
|  | HSDPA in use |  | EDGE in use |
|  | GPRS in use |  | Roaming |
|  | GPS is on |  | Bluetooth is on |
|  | Battery is charging |  | Battery is full |
|  | Battery is very low |  | Missed call |
|  | New message |  | An open Wi-Fi network is available |
|  | Connected to a Wi-Fi network |  | Uploading data |
|  | Downloading data |  | microSD card is full |
|  | Problem with sign-in or synchronisation |  | USB tethering is on |
|  | Portable Wi-Fi hotspot is on |  | Google Play Music is running |
|  | Battery Saver |  | Alarm is set |
|  | Data Roaming is on |  | Data Roaming is off |
|  | Headset connected | | |

1.10 Notification panel


Pull down the Status bar to open the Notification panel. You can view phone network information, new events, etc.




From the Notification panel, you can do any of the following:











- Quickly open or close relevant applications.
- Touch  to clear all notifications.
- Pull up from the bottom of the panel to close the Notification panel.

Using the Quick Settings button


Open the Notification panel and touch  to switch to the Quick Settings button panel. Dragging down the status bar with two fingers also opens the Quick Settings panel.



In the Quick Settings button panel, you can configure the following settings:



- Touch  to set the brightness.
- Touch  to open the Settings.
- Touch  to check the Wi-Fi settings, and long press to turn Wi-Fi on or off quickly.
- Touch  to change mobile data usage.
- Touch  to check the battery status.
- Touch  to turn Aeroplane Mode on or off.
- Touch  to open the Bluetooth settings, and long press to turn Bluetooth on or off quickly.
- Touch  to open the Location settings, and long press to turn Location on or off quickly.
- Touch  to open the Battery Saver settings, and long press to turn Battery Saver on or off quickly.
- Touch  to turn Data Roaming on or off.

1.11 Managing applications



On the Home screen, touch  to enter the applications list. In the applications list, you can do any of the following:

- Touch an application icon to open it.
- Swipe left or right to view another list screen.
- Touch and hold an application icon, and drag it onto the Home screen.


1.12 Managing Home screen

- On the Home screen, touch  (Menu key) >  to enter the widgets list.
- In the widgets list, touch and hold a widget, and drag it


onto the Home screen.

- On the Home screen, touch  (Menu key), touch and hold a Home screen panel to rearrange the order.
- On the Home screen, touch and hold a shortcut or widget and drag it to the  to delete it.

Tip: To help you set up your phone the way you like it,




drag  from the right-most Home screen to the main Home screen, so you can access it more easily.

1.13 Managing folders



- **Add folders:** On the Home screen, touch and hold an application icon and stack it on top of another application icon to create a folder.
- **Rename folders:** On the Home screen, touch a folder and then touch the folder name in the popup to rename the folder.
- **Delete folders:** On the Home screen, touch and hold a folder and drag it to the  to delete it.
- **Move folders to the shortcut bar:** When there is space on the shortcut bar at the bottom of the screen, touch and hold a folder and drag it to the shortcut bar.

2. Phone calls

You can make a phone call from the keypad, People or the Call log. While you are in a call, you can also answer another incoming call, send it to your voicemail or conduct a conference call.


Touch  at the bottom of the Home screen or touch  >  to open the dial application.

2.1 Making a call



- On the dial application screen, touch  to open the keypad.
- Touch the number keys to enter the telephone number.
- Touch  at the bottom of the screen to dial the number.

Hint: To avoid affecting the quality of the call, do not touch the receiver or loudspeaker when making or answering a call.

Making a call from Contacts




- On the dial application screen, touch  to open the All contacts list.
- Touch a contact to make the call.


Making a call from Call log

- On the dial application screen, touch  to view the call log.
- Touch  on the right side of the Call log to make the call.

2.2 Answering or rejecting a call







When you receive an incoming call, you can do any of the following:

- Answer the call: Slide to  on the right to answer the call.
- Reject the call: Slide to  on the left to reject the call.
- Rejection SMS: Slide to  upward to reject the call and send an SMS message to the caller.

Hint: On the dial application screen, press  (Menu key) > Settings > Quick responses to edit the rejection SMS.

2.3 During a call





On the call screen, you can do any of the following:


- Hang up the call: Touch  to hang up the call.
- Enter another number: Touch  to open the keypad and enter another number.
- Turn on Speakerphone: Touch  to hear the caller on the loudspeaker (so you don't need to hold it to your ear).
- Mute: Touch  to mute the call so that the other person cannot hear your voice.
- Hold the call: Touch  to put the current call on hold.
- Add a third person to the call: Touch  to enter the dial screen and add a third person to the call.

Hint: You can touch and use other functions during a call. To return to the call screen, open the Notification panel and touch the current call.

2.4 Conference calls

You can hold a conference call with multiple participants.

- Place a call to the first participant.
- Touch  during the call with the first participant.
- Use the keypad to enter the phone number of the second participant you want to add, or touch  or  to select the number.
- After connecting with the second participant, touch  to start the conference call.

- Touch  to end the conference call.

Hint: You can have up to 6 participants in conference call mode. See the Vodafone website or contact Vodafone customer services for details.

2.5 Answering another incoming call

If you receive another incoming call while you are in a call, you can accept the incoming call and automatically place the current call on hold without hanging up.

Hint: You need to enable call waiting before you can use this service. See the Vodafone website or contact Vodafone customer services for details.


2.6 Supplementary services

Your phone supports a variety of supplementary services. These include call forwarding and call waiting.

Hint: These services require network support. See the Vodafone website or contact Vodafone customer services for details.

Setting up call forwarding


If you are unable to answer calls, you can set up this function to forward incoming calls to another number.

- On the dial application screen, touch  (Menu key) > Settings > Call forwarding.
- Select a forwarding type, enter the number you want to forward calls to.
- Select Enable to enable this function.

Setting up call waiting


After setting up this function, the phone will notify you if you receive an incoming call while already in a call. It will also inform the incoming caller to wait for you to end your current call before they are connected. You can also

answer the incoming call and switch between the two calls.

- On the dial application screen, touch  (Menu key) > Settings > Additional settings > Call waiting.
- Mark the Call waiting checkbox to enable this function.

2.7 Voicemail

If you activate and set up voicemail, your phone will automatically send unanswered calls to voicemail (including calls that are unanswered when you are in another call and when your phone is off).


- On the dial application screen, touch  (Menu key) > Settings > Voicemail > Setup.
- Touch Voicemail number, enter your voicemail number and then touch OK to set up voicemail.
- To listen to your voicemail, press and hold the 1 key on the dial keypad screen and follow the server instructions.

Hint: Before using this function, contact Vodafone customer services to activate voicemail. See the Vodafone website or contact Vodafone customer services for details.


3. People


You can use the People application to save and manage phone numbers, addresses and other information.

To open the People application, swipe the main Home screen to the right to reveal another Home screen, then

touch . You can also touch  > .

3.1 Adding a contact

- On the Contacts screen, touch .
- Select where to save the contact.

- Enter the contact information.
- Touch  **DONE** to save the contact information.



Hint: In the Call log, touch a phone number you want to save to save it directly as a contact.

3.2 Quick Contact


On the Contacts screen, touch the avatar (image) of a contact and select the icon for the way you want to communicate with the contact. You can quickly call the contact or send them an SMS or email. The icons available depend on the information you have for the contact and the applications and accounts on your phone.

3.3 Managing contacts

Adding a contact to Favourites




On the Contacts screen, select the contact you want to add to Favourites and then touch the  at the right of the contact name. The star will fill colour () to indicate that the contact has been added to Favourites.

Searching for a contact

- On the Contacts screen, touch .
- Enter the name of the contact you want to search for. Search results will be displayed below the search bar.


Hint: You can also slide the scroll bar at the right of Contacts to quickly search for a contact.

Editing a contact

- On the Contacts screen, select the contact you want to edit then touch  (Menu key) > Edit.
- Edit relevant information and then touch  **DONE** to save the contact. Alternatively, touch  (Menu


key) > Discard to cancel your changes.

Deleting a contact

- On the Contacts screen, select the contact you want to delete then touch  (Menu key) > Delete.
- Touch OK to confirm that you want to delete the contact.






Sending a contact vCard

You can send a “.vcf” format vCard via email, Bluetooth or MMS. Before using email to send a vCard, you need to set up an email account on the phone. (Read the “7.1 Adding an email account” section of this user manual, on page 21.)

- Touch a contact on the Contacts screen.
- Touch  (Menu key) > Share.
- Select how to send the vCard.


3.4 Managing groups

Creating a group

- On the Contacts screen, touch  to switch to the Groups screen.
- Touch  and select an account.
- Enter the group name.
- Touch , select one or multiple contacts and then touch .
- Touch  to save the group information.

Editing a group

You can always make changes to the information you have stored for a group.

- Select a group and touch  (Menu key) > Edit.
- Edit the group name and add or delete members.



- Touch  **DONE**.

Adding a contact to your groups

To add a contact to your groups, you can do any of the following:

- When editing contact information, touch the group names below **GROUPS** to select groups.
- When editing a group, enter a contact name. The phone will automatically display the names of stored contacts as you enter the name. Touch the contact you want to add to the group.

3.5 Importing contacts from SIM card or storage

- On the People screen, touch  (Menu key) > Import/export, and select the corresponding option.
- Select one or multiple contacts.
- Touch  to finish copying the contact(s).

Hint: Read the “Frequently Asked Questions” section of this user manual to get more information about how to import contacts from another phone by using the microSD card, on page 47.)

4. Text input methods

4.1 Using the text input panel





The input panel can be used to enter text. When you need to enter text, touch the text input area to open the input panel. Touch Back key to hide the input panel.

4.2 Switching input methods











When you installed other different input methods, you can switch the input methods.

- When the keyboard is displayed on the screen, gently slide down the Status bar to open the Notification Panel.
- Touch Select Input Method and select the input method you want to use.


Hint: Touch  >  > Language & input > Default, then select which input method to set as the default.

4.3 Editing text

Touch and hold the text you have entered and select the content you want to edit. You can use the icons that appear on the top right of the screen to quickly edit the text.




- : Select all text.
- : Cut selected text. Touch and hold the text you have entered, move the cursor to select the text you want to edit and touch this icon to cut the text. After cutting, you can touch and hold a blank area in the text field until  appears. Move  to the location where you want to paste the text and then touch  to paste the text you previously cut.
- : Copy selected text. Touch and hold the text you have entered. Move the cursor to select the text you want to copy and touch this icon to copy the text. After copying, you can touch and hold a blank area in the text field until  appears. Move  to the location where you want to paste the text and then touch  to paste the text you previously copied.
- : Replace text. Touch and hold the text you have entered. Move the cursor to select the text you want to replace and touch this icon to replace the selected text with the text you previously cut or copied.

4.4 Horizontal keyboard


If you have enabled auto-rotate (in  > Display), rotate the phone when entering text to switch to a horizontal onscreen keyboard for easier input.

4.5 Input method settings

After selecting an input method, you can configure its specific settings.




- On the right-most Home screen touch  > Language & input, or touch  >  > Language &

input.

- In Keyboard & Input Methods, touch  next to an input method to configure its settings.

5. Message+

Message+ allows you to share the photo, video and audio to your friends, it also allows you to make chat or group chat with your friends.

Touch  at the bottom of the Home screen or touch  >  to open the Message+.



5.1 Verify number

You should verify your number on first start up.

- Follow the onscreen instructions to enter your phone number.
- Touch OK to confirm the number.
- The app will connect to the Message+ provisioning system and sends back a hidden confirmation SMS. If the SMS has been received after a specific time, the app is registered and starts.



Hint: Make sure you already connected to the internet to activate the Chat & File Share.

5.2 Start a message


- On the Message+ screen, touch .
- Choose the recipients and add your message. Touch  to choose the attachment you want to share, such as photo, video, location, file, etc.
- Touch Send to send the message.
- You can check the status of message after you sent.

Hint: The message will be sent as an SMS/MMS if your friends didn't activate Message+.



5.3 Start a group chat

- On the Message+ screen, touch .
- Enter the topic for this chat group.
- Type a name or number to search the contact. Or you can touch  to choose the contact. Then start your chat.
- Touch the chat title to check the status of your friends or add a new contact to this group when during a chat.





5.4 Settings

On the Message+ screen, touch  (Menu key) > Settings to configure Look & Feel, Chat & SMS, Sharing, Notifications, etc.

6. Messaging


On the Home screen touch  >  to open the Messaging.

6.1 Creating a message


- On the Messaging screen, touch .
- Enter the recipient's number or you can touch  to select contacts.
- Add your message. Touch  to attach media files such as photo, audio and slides.
- Touch  to send the message.

Hint: An SMS will be sent as an MMS when media files are added.


6.2 Replying to a message

- On the Messaging screen, select the message you want to reply to.
- Compose your message and touch  to send it.


6.3 Searching messages

On the Messaging screen, you can touch  and enter message content or keywords to quickly search for the message you need.

6.4 Deleting a message




On the Messaging screen, touch and hold the message conversation you want to delete. Touch  to delete the message conversation.

6.5 Customising message settings

On the Messaging screen, touch  (Menu key) > Settings to configure SMS, MMS, message notifications and other settings.

7. Email

You can use the email application to send and receive emails.


Touch  on the Home screen or touch  >  to open the Email.

7.1 Adding an email account

You must configure an email account before you can send and receive emails. Sending and receiving emails requires you to have a Vodafone data service for your phone. This is usually part of your Vodafone price plan.

- Select an account, enter the email address and password, and then touch Next. Follow the onscreen instructions to configure the relevant settings.

Hints:

1. After creating your initial email account, from the Inbox screen you can touch  (Menu key) > Settings > ADD ACCOUNT to add another email account.
2. Set up your email account according to the instructions provided by your email service provider. Log on to the email service provider's website for specific settings.

7.2 Switching accounts

On the Inbox screen, touch the email address field at the top of the screen. Select an email account from the list that is displayed. After making your selection, the Inbox for the selected account will be opened automatically.



7.3 Combined account view

You can show the Inbox emails from all your accounts on one screen. On the Inbox screen, touch the email address field at the top of the screen, then select Combined view.


7.4 Viewing emails

On the Inbox screen, touch the email you want to view to open it.

7.5 Creating and sending emails




- On the Inbox screen, touch .
- Touch the To field and enter the recipient's email address. Or you can touch  to select contacts.
- Enter the subject and content of the message in the

relevant fields.


- Touch  to send the email.

7.6 Replying to and forwarding emails

On the Inbox screen, touch the email you want to reply to.

- Touch  to reply directly to the sender.
- Touch  > Reply all to reply to everyone.
- Touch  > Forward to forward the email.




7.7 Saving email attachments

- On the Inbox screen, touch the email you want to view.
- Slide down to find the attachments after the content.
- Touch  > Save to download the attachment.

Hints:

1. If your phone has a microSD card installed, the downloaded file will save to the download folder (/storage/external_sd/Download) in microSD card by default.
2. You can change the default storage location in Settings > Storage > DEFAULT WRITE DISK.

7.8 Deleting an email account

- On the Settings screen (On the Home screen touch  > )
- In ACCOUNTS, touch an email account.
- Touch the name of account, then touch  (Menu key) > Remove account to delete the account.



7.9 Customising email account settings

- On the Inbox screen, touch  (Menu key) > Settings to enter the account settings screen.

- Touch an email account.
- Change account settings such as data usage, notification settings, server settings, etc.

8. Data service

8.1 Turning on the data service



- Touch  > .
- In WIRELESS & NETWORKS, touch More... > Mobile networks.
- Mark the Data enabled checkbox to turn on the data service.
- Mark the Data Roaming checkbox to turn on the data roaming service.

Hints:

1. To extend standby time and save data usage, switch off the data service when network services are not needed.
2. Using mobile networks while roaming may incur additional charges. See the Vodafone website for details.
3. The phone's access points have already been configured for you. Do not change access point parameters without permission; otherwise you may be unable to access networks.

8.2 Wi-Fi


You can use the phone's Wi-Fi function to access the Internet and pick up and send emails.

- Touch  > .
- In WIRELESS & NETWORKS, touch Wi-Fi switch to turn on/off Wi-Fi.
- In WIRELESS & NETWORKS, touch Wi-Fi to enter the Wi-Fi settings screen. The phone will search for and list

nearby Wi-Fi hotspots.

- Select the Wi-Fi hotspot you want to connect to. If the network you selected is secured, you are required to enter a password before you can connect.

Hints:


1. If you turn on Wi-Fi and the data service simultaneously, the phone will automatically use the Wi-Fi connection. If Wi-Fi is disconnected, the phone will use the data service to continue the data connection.
2. On the Wi-Fi settings screen, touch  and configure authentication to add a new Wi-Fi hotspot SSID (service set identifier).
3. Wi-Fi signals may be obstructed and weakened by obstacles like walls.

Connecting to Wi-Fi using WPS

WPS (Wi-Fi Protected Setup), also called quick secure setup, is an operation that can simplify Wi-Fi connection settings. You can simply press the WPS button or enter a PIN number to automatically establish a secure connection. There is no need to configure complicated settings in the Wi-Fi hotspot administration software.


Hint: When using WPS to connect to a Wi-Fi hotspot, make sure that the Wi-Fi hotspot supports WPS; otherwise you will be unable to use this function.

WPS button connection

- Enable Wi-Fi.
- On the Wi-Fi settings screen, touch .
- Press the WPS button on the Wi-Fi hotspot device.

WPS PIN number connection

- Enable Wi-Fi.

- On the Wi-Fi settings screen, touch  (Menu key) > WPS Pin Entry. The phone will automatically create a PIN number.
- Enter this PIN number into the Wi-Fi hotspot device.

Hint: You can also connect by creating a PIN number using the Wi-Fi device and entering this PIN number into the phone.



8.3 Sharing your phone's data connection

You can share your phone's mobile network with a single computer via a USB data cable. This is called USB tethering. You can also share your phone's mobile network as a portable Wi-Fi hotspot or Bluetooth.

Hint: Using this function may incur additional data charges, depending on your data plan. See the Vodafone website for more details, or contact Vodafone customer support.

Sharing your phone's mobile network via USB



If your computer's operating system is Windows XP or a later or a new release of Linux (e.g. Ubuntu 10.4), you can use USB tethering without changing any settings on your computer. If you use USB tethering with computers with different operating systems, you may need to establish corresponding network connections on each computer.

- Touch  > .
- In WIRELESS & NETWORKS, touch More... > Tethering & portable hotspot.
- Mark the USB tethering checkbox to share your phone's mobile network with a computer and use the computer to connect to the internet.

Hint: While you are sharing your phone's data connection via USB tethering, you cannot set the microSD card as a mass storage device.

Sharing your phone's data connection as a portable Wi-Fi hotspot

By setting your phone as a Wi-Fi hotspot you can connect up to eight wireless devices at most.




- Touch  > .
- In WIRELESS & NETWORKS, touch More... > Tethering & portable hotspot.
- Touch the Portable Wi-Fi hotspot checkbox to activate the Wi-Fi hotspot and share your mobile network.

Hints:

1. You can touch Set up Wi-Fi hotspot to set the name, security and password for the Wi-Fi hotspot. To protect your network, it is recommended that you secure it using WPA2 PSK.
2. You cannot use Wi-Fi hotspot and Wi-Fi at the same time.

Sharing your phone's data connection via Bluetooth

You can also use the Bluetooth to sharing your mobile networks.




- Touch  > .
- In WIRELESS & NETWORKS, touch More... > Tethering & portable hotspot.
- Touch the Bluetooth tethering checkbox to share your mobile network.
- In WIRELESS & NETWORKS, touch Bluetooth, in PAIRED DEVICES list, touch  of device that you want to share the mobile network. In device settings screen, touch the Internet access checkbox to allow the internet access.

8.4 Bluetooth

Your phone supports Bluetooth, which allows you to create a wireless connection with other compatible devices so you can share data.

Hint: Bluetooth has a maximum reception distance of 10 meters. Keep devices connected by Bluetooth within 10 meters of each other. Obstacles like walls or other electronic equipment may interfere with Bluetooth signals.

Turning on Bluetooth


- Touch  > .
- In WIRELESS & NETWORKS, touch the Bluetooth switch to turn on Bluetooth. The Status bar will display the Bluetooth icon.
- If you need to change the device name of your phone, touch  (Menu key) > Rename phone. Enter a name and touch Rename to save your change.

Searching for and pairing with other Bluetooth devices

You need to pair with a Bluetooth device before you can share data with it. Once a device is paired with your phone, it will automatically connect to your phone whenever it is turned on.


- Check your phone's settings to make sure that the Bluetooth is enabled.
- In WIRELESS & NETWORKS, touch Bluetooth list to enter the Bluetooth settings screen. The phone will automatically scan for nearby Bluetooth devices.
- Touch the one that you want to pair with and follow the onscreen instructions to pair with it. If you don't know the password for the device you're trying to pair with, try 0000 (this is the default password for most BT

devices).




- If you want to unpair, in Paired devices touch  > Unpair to stop it connecting automatically. You can always go through the pairing process again if you change your mind.
- To stop a connection with a Bluetooth device, the simplest way is to turn the device off. Otherwise, just turn Bluetooth off on your phone using the Quick Settings menu.

Sending files via Bluetooth



With Bluetooth, you can share pictures, videos or music files with your family and friends.

- In ES File Explorer application, touch and hold the file you want to send. After the file has been selected, touch  > Share, on the options menu that pops up, select Bluetooth.
- The screen will list the Bluetooth devices that have been found. Select the device you want to send the file to.

9. Browser

Touch  at the bottom of the Home screen or touch  >  to open the Browser.


9.1 Browsing web pages

- Enter a web page address in the URL field at the top.
- Touch  on the top right of the screen to browse thumbnails of multiple open web pages and switch to any web page window.
- Touch  to open a new window.


Hint: If you have installed other browsers, it will pop up a selection for choosing browsers when you click a web link.

9.2 Managing bookmarks


Adding a bookmark

- Use the browser to open the web page you want to bookmark.
- Touch  (Menu key) > Save to bookmarks.
- Enter the bookmark name and touch OK to add the bookmark.


Opening a bookmark

- On the browser screen, touch  (Menu key) > Bookmarks.
- Select the bookmark of the website you want to view.
- On the Bookmarks screen, touch the History tab to view the web pages you have visited.

9.3 Setting a home page




- On the browser screen, touch  (Menu key) > Settings > General > Set homepage.
- Select a home page from the list or touch Other to enter a web address and then touch OK to save the home page.

9.4 Customising browser settings


- On the browser screen, touch  (Menu key) > Settings.
- On the Settings list, you can select menus to customise the browser.

10. Camera and video camera

You can use your phone to shoot and share both photos and videos. Your camera supports numerous modes.

Touch  at the bottom of the Home screen or touch  >  to open the Camera. On the Lock screen, slide from right side of screen to left, can open the Camera quickly.

10.1 Taking a photo




- Open the camera and aim the lens at the subject.
- Touch the screen where you want to focus, when the lines in the circle turn green, then that point is in focus.
- Pinch or spread in the viewfinder, you can change the focal length.
- Touch  to take the photo.



- Before you take a photo you can touch and hold anywhere on the screen to see the camera options. You have to keep touching and slide onto the option button, then select the option or value.

Hint: For a better result, you can open the settings menu and adjust camera parameters before taking the photo. The viewfinder will change accordingly after you have adjusted the settings.




10.2 Recording a video

- Open the camera and aim the lens at the subject.
- Touch the Camera icon on the lower left of the screen, and select  to activate video mode.
- Pinch or spread in the viewfinder, you can change the focal length.
- Touch  to start recording.
- Touch  to stop when you finish recording.
- Before you record a video you can touch and hold anywhere on the screen to see the options. You have to keep touching and slide onto the option button, then select the option or value.

Hints:



1. To share the video via MMS, the video size should be less than 300K.
2. For a better result, you can open the settings menu and adjust camera parameters before recording the video. The viewfinder will change accordingly after you have adjusted the settings.

10.3 Panoramic mode

- Open the camera, touch the Camera icon on the lower left of the screen, and select  to activate panoramic mode.
- Touch  to start capturing panorama.
- You can check the progress under the viewfinder.
- Touch  to stop when you finish.



After taking your photo or video, you can slide from right to left to view the photo or video you just took.

When viewing a photo or video, you can do any of the following:

- Touch  to send the photo or video to a friend via MMS, email, Bluetooth or another method.
- Touch  to delete the photo or video.

11. Gallery


You can use the Gallery to manage picture and video files.

On the Home screen touch  >  to open the Gallery.

11.1 Viewing pictures and videos








- On the library screen, touch the folder you want to view.
- Touch the picture or video you want to view.

11.2 Editing a picture



When viewing a picture, touch  to edit it.




On the editing screen, you can do any of the following:

- : Perform photo effects such as Punch, Vintage, B/W, Bleach, etc. on the image.
- : Perform photo border on the images.
- : Perform operations such as Crop, Straighten, Rotate and Mirror on the image.
- : Perform operations such as Autocolour, Exposure, Vignette, etc.
- : Undo the last step.
- : Redo the operation.
- Touch  **SAVE** to save a picture after you have finished editing it.


12. Google Play™ Music

On the Home screen touch  >  to open the Google Play Music.


On the Google Play Music screen, touch  in the upper left of the screen to switch between Listen Now, My Library and Playlists.

My Library contains the following tabs: GENRES, ARTISTS, ALBUMS and SONGS. You can slide left and right to view and select the content of each tab.

Hints:

1. You can play music files stored on the microSD card in your phone. Music files can be downloaded from computer to microSD card by using an USB cable.
2. Touch  > Help to get more introductions from Google Play.

12.1 Adding music to a playlist

- Touch  on the music file that you want to add to a playlist.
- On the options menu that pops up, touch Add to playlist.
- On the playlist that pops up, select a playlist to add the song to it.






12.2 Playing a playlist

- On the Playlists screen, touch the playlist you want to play.
- Touch the cover of the playlist to play this playlist.

12.3 Playing a music file

- On the My Library screen, slide to SONGS tab.
- Touch a music file to play it.
- Touch or slide up the bottom of the screen to see the music playback screen.

On the music playback screen, you can do any of the following:




- Touch  to enter the playlist screen.
- Check music playback progress.
- Touch  to pause or touch  to resume. Touch  to play the next song. Touch  to play the previous song.
- Touch or slide down the top of the screen to back to the My Library.

Hints: During music playback, touch the Home key to go back to the Home screen. The music will continue to play in the background and you can use other applications. Open the Status bar and select the currently playing song to go back to the music playback screen.

13. Accounts and syncing

Use the Accounts settings to add, remove, and manage your accounts. It includes Corporate, Email, Facebook, Google, Twitter and other supported accounts. You can also use these settings to control how and whether all applications send, receive, and synchronize data on their own schedules, and whether all applications can synchronize user data automatically.

Gmail, Google Calendar, and other applications may also have their own settings to control how they synchronize data.

On the right-most Home screen touch  or touch  > . In ACCOUNTS, you can see the accounts you already added or manage your accounts.

13.1 Adding an account

- In ACCOUNTS, touch Add account.
- Select the kind of account to add.
- Follow the onscreen instructions to enter the required information about the account.
- Configure the account. Set what information you want to sync to the phone.
- When you are finished, the account you configured is added to ACCOUNTS.

Hint: The information you are able to configure for syncing depends on the kind of account you added.

13.2 Enabling syncing

- In ACCOUNTS, select the account you want enable syncing for.
- Mark the check box to permit applications to synchronise data on their own schedule.

14. More applications

14.1 Calendar

You can use Calendar to manage and arrange events.



On the right-most Home screen touch  or touch

 >  to open the Calendar.

Multimode view


On the Calendar screen, you can display the Calendar in daily, weekly, monthly, or agenda view. Touch the time in the upper left of the screen to switch between Day, Week, Month and Agenda view.

Adding a new event


- On the Calendar screen, touch  (Menu key) > New event.
- Edit upcoming event information such as a name, location, time, etc.
- Touch  to save the event.

Hint: You can double touch any day on the screen to create a new event. You can also tap and hold for a Quick Event entry.

Customising Calendar settings

On the Calendar screen, touch  (Menu key) > Settings to configure Calendar.


Setting an event reminder

- On any calendar view, touch an event to view its details or summary.
- Touch Add reminder to add a reminder for the event. Alternatively, touch  to delete a reminder that has already been set.

- Touch the reminder time. In the drop-down list that opens, select a time period to set the length of time before the event when you want to be reminded. When the time comes, you will receive a notification or an email about the event.

Syncing and displaying the Calendar

Calendar events for accounts (e.g. email accounts) that have been added to your phone can be synced to and displayed in your Calendar application.

- On any Calendar view, touch  (Menu key) > Calendars to display.
- Mark the check box to enable or disable syncing.

Hint: If you have already configured an account to sync events to your phone, that account will appear on the Calendars to display list.

14.2 Alarm clock



On the Home screen touch  >  to enter the Clock

screen, and then touch  to switch to the Alarm tab.

On the alarm list screen, follow the instructions below to set your alarm:




- Touch Time to set the time of the alarm.
- Mark the REPEAT check box to set the days when you want the alarm to sound.
- Touch Ringtone to select a ringtone for the alarm.
- Mark the VIBRATE checkbox to have the phone vibrate, in addition to playing the ringtone.
- Touch Label to enter a name for the alarm.
- Touch the switch of the alarm to turn on the alarm.

14.3 Calculator

On Home screen touch  >  to open the Calculator.

On the Calculator screen, swipe the screen right or left to switch between the Advanced panel and Basic panel.

15. Settings

On the right-most Home screen touch  or touch  >  to configure detailed phone settings.

15.1 Setting the date and time

- On the Settings screen, touch Date & time.
- Unmark the Automatic date & time checkbox.
- Unmark the Automatic time zone checkbox.
- Touch Set date. Slide up and down to adjust the date and then touch Done.
- Touch Set time. Slide up and down to adjust the time and then touch Done.
- Touch Select time zone and then select the desired time zone from the list. Scroll the list to view more time zones.
- Mark or unmark the Use 24-hour format checkbox to switch between 24-hour format and 12-hour format.
- Touch Choose date format to select how you want the date to display on your phone.

Hint: When your phone is using date and time settings provided automatically by the network, you cannot manually set the date, time and time zone.

15.2 Setting the display

On the Settings screen, touch Display to set the screen display.

- **Brightness:** Set the brightness of the display. Touch AUTO to turn off the auto-brightness, or adjust the brightness manually.
- **Wallpaper:** Change the background picture of the Home screen.
- **Home screen:** Mark or unmark this checkbox to turn on or off loop panels function.
- **Auto-rotate screen:** After setting this function, the phone will automatically switch orientation if you rotate the phone while browsing web pages, viewing pictures, editing information and performing other operations.
- **Sleep:** Set the screen sleep time. Your screen will automatically turn off if no operations are performed within the time set.
- **Key light duration:** Set the touch key light duration time.
- **Daydream:** When Daydream is on, your device displays photos, colours, and more while it is charging or docked. Set the daydream type or when to daydream. Touch the daydream switch to turn off this function.
- **Font size:** Set the font size according to your preference.
- **Pulse notification light:** Mark or unmark this checkbox to control the phone's light pulse when has a new notification.
- **Wireless display:** When you turn on this function, the phone will automatically search for nearby displays.

15.3 Adjusting the volume

You can use the Volume key to adjust the volume from the Home screen or many application screens. For example, during a call or when playing music or videos. You can also adjust the volume using the following

method:

- On the Settings screen, touch Sound.
- Select Volumes and drag the slider left to make the volume lower, or right to make it higher.
- Touch OK to save the adjustment.

15.4 Changing the phone ringtone

- On the Settings screen, touch Sound > Phone ringtone.
- On the options menu that pops up, select a path of the ringtone.
- Select the ringtone you want to use.


15.5 Managing applications

On the Settings screen, touch Apps to open a list of all applications.

Viewing and uninstalling applications

- Touch an application to view its information.
- If you want to uninstall the application, touch Uninstall and follow the onscreen instructions.

Hints:

1. Some applications are subject to system restrictions and cannot be uninstalled. The Uninstall option will not appear on the Application info screen for such applications.
2. On the list of all applications, touch  (Menu key) > Sort by size to rearrange applications by file size.

Moving larger applications to microSD

The storage location of some applications can be changed. Moving larger applications to microSD card can free up more space to store applications that cannot be moved.

- Touch the application you want to move and then touch Move to SD card to move the entire application out of the phone's internal storage.
- Touch Move to phone to move the application back to the phone's internal storage.

Hints:

1. The Storage list on the Application info screen displays detailed data showing which storage space the application occupies.
2. If the application can be moved, you can use a move button.

15.6 Security settings

Turning on screen unlock pattern protection

You can set a screen unlock pattern. Once the screen has locked, it needs to be drawn correctly in order to unlock the screen.

- On the Settings screen, touch Security > Screen lock > Pattern.
- Follow the onscreen instructions to draw the unlock pattern.
- Touch Continue.
- Draw the same unlock pattern again and touch Confirm.

Turning on numeric PIN protection

You can set a numeric PIN to lock your phone. Once the screen has locked, it needs to be entered correctly in order to unlock the phone.

- On the Settings screen, touch Security > Screen lock > PIN.
- Enter at least four-digit numbers.
- Touch Continue.
- Enter the same number again and touch Confirm.

Turning on SIM card PIN protection

A PIN (personal identification number) can prevent other people using your SIM card without permission. A PUK (personal unlock key) can be used to unlock a blocked PIN. If an incorrect PIN is entered three times in a row, your SIM will be blocked. To unblock your SIM, you'll need to enter your PUK. If the wrong PUK is entered ten times in a row, your SIM will be blocked permanently. If these two codes were not provided with your SIM card or if you forget either one, contact Vodafone customer services. If you turn on SIM card PIN protection, your SIM card PIN needs to be entered every time you turn on your phone.

- On the Settings screen, touch Security > Set up SIM card lock.
- Mark the Lock SIM card checkbox.
- Enter the SIM card PIN and touch OK to turn on PIN protection.

Hint: To change your SIM card PIN, touch Change SIM PIN.

16. NFC

NFC (Near Field Communication) is a new, short-range wireless connectivity technology which allows mobile users to read and write NFC tags, pair with other NFC devices, and even make fast and secure mobile payments. With NFC activated, you can use this application to open, act on and organize the tags you've scanned. In Settings > WIRELESS & NETWORKS, touch More..., check NFC to turn on/off NFC function.

Tap & pay

When NFC is turned on, you can use the tap & pay feature to pay for items just by touching your phone to a reader

at a register.

To manage your apps for the tap & pay option, follow these steps:

- On the Settings screen, touch Tap & pay.
- Touch an app to make it your default payment app.

If your device doesn't have a default app, you can browse Google Play™ for other payment apps.

Hints:

1. The tap & pay option doesn't apply to Android Beam and won't include certain apps, such as money transfer apps.
2. NFC is only available in some countries/areas.

17. Location access

You can let your device access GPS, Wi-Fi networks, and mobile networks to estimate your location. Apps that have your permission can use this information to deliver location-based services, such as the ability to check in, view commute traffic, or find nearby restaurants.

To control what location information your device can use, go to Settings > PERSONAL > Location.

When the Location switch is on, you can do any of the following:

- Change the location mode between High accuracy, Battery saving and Device only.
- Check the Recent location requests.
- Check the Location services.
- AGPS Setting: Touch to set the AGPS server address and the port.

Hint: Using location access does make more demands on your battery. If you need to save battery life then you can turn it off in Settings, though when the switch is off, your device won't be able to find your precise location or

share it with any apps.

18. Restoring factory settings




Restoring factory settings erases all of your personal data stored on the phone, including email accounts, system settings, application settings, and any applications you have installed.

- On the Settings screen, touch Backup & reset > Factory data reset.
- Follow the onscreen instructions and touch Reset phone. Then touch Erase everything. The phone will restore the factory settings and restart automatically.

Warning: Before restoring factory settings, it is vital that you first back up any important data on the phone; otherwise all data will be lost after factory settings have been restored.

19. FOTA (Firmware Over The Air) updating

Using the FOTA Upgrade tool you can update your phone's software.

- On the right-most Home screen touch  > About phone > System updates, or touch  >  > About phone > System updates.
- Touch Check for updates, and the phone will search for the latest software. If you want to update the system, please touch the button Download, after it done please touch Update now to complete the upgrade. Then your phone's software will have the latest version.

Hints:

1. During FOTA downloading or updating, do not change your default storage location, to avoid errors in locating the correct update packages.
2. Upgrading your phone software will not affect your mobile phone data.

Frequently Asked Questions

How do I free up my phone's internal storage?

- Move files and email attachments to the microSD card.
- In Browser, clear all temporary Internet files and Browser history information.
- Uninstall any applications that you no longer use.
- Reset your phone to factory settings.




How can I use the microSD card to import contacts from another phone onto my phone?

Your phone supports “.vcf” format contact files. “.vcf” is the standard format for storing personal and company contacts. It usually includes name, address, telephone number, mobile phone number, email and other contact information. It also supports custom fields, pictures and other media information.




- Back up the contact you want to import as a “.vcf” file and save it to the microSD card.
- Insert the microSD card into your phone. In ES File Explorer, find the “.vcf” file saved on the microSD card.
- Touch the “.vcf” file. On the window that pops up, select the account you want to import the contact to.

Hint: Because “.vcf” files backed up by different systems may cause compatibility problems, some contact information may be lost after the contact has been imported.

How do I turn off auto-rotate?

- On the right-most Home screen touch  > Display, or touch  >  > Display.
- Unmark the Auto-rotate screen checkbox to disable this function.

How do I set the screen unlock pattern?

- On the right-most Home screen touch  > Security > Screen lock > Pattern, or touch  >  > Security > Screen lock > Pattern.
- Follow the onscreen instructions to set the unlock pattern.

How do I switch input method?

When you installed other different input methods, you can switch the input methods.

- When the keyboard is displayed on the screen, gently drag down the Status bar to open the Notification Panel.
- Touch Choose input method and select the input method you want to use.

How do I stop music playing in the background?

Gently drag down Status bar to open the Notification panel. Touch the music playback information bar to enter the music playback screen and stop playback.

How do I return to the call screen?

If you are in another screen during a phone call, you can get back to the call screen by gently dragging down the Status bar to open the Notification panel and the touching the current call.

How do I create a shortcut on the Home screen?

On the applications list, touch and hold an application icon until the Home screen is displayed. Then drag the icon where you want it to go and release your finger.

How do I hide the keyboard?

Touch Back key to hide the keyboard when it is displayed on the screen.

How do I forward a message?

Touch and open the message you want to forward. Touch and hold the message content. On the options menu that pops up, touch Forward.

How do I take a quick capture of the current screen?

Press the Volume key (Down) and Power key at the same time, and make a little pause to take a capture of the current screen.

If your phone has a microSD card installed, the screenshots will save to the screenshots folder (/storage/external_sd/Pictures/Screenshots/) in microSD card by default.

Product Safety Information

Pictograms and Graphic Symbols

- | | | | |
|--|---|---|---|
|  | Read the Safety Information section of this user guide on page 51 |  | Do not use while re-fuelling |
|  | Do not use hand-held while driving |  | This device may produce a bright or flashing light |
|  | For body-worn operation maintain a separation of 15 mm |  | Do not dispose of in a fire |
|  | Small parts may cause a choking hazard |  | Avoid contact with magnetic media |
|  | This device may produce a loud sound |  | Avoid Extreme Temperatures |
|  | Keep away from pacemakers and other personal medical devices |  | Avoid contact with liquid, keep dry |
|  | Switch off when instructed in hospitals and medical facilities |  | Do not try and disassemble |
|  | Switch off when instructed in aircrafts and airports |  | Do not rely on this device for emergency communications |
|  | Switch off in explosive environments |  | Only use approved accessories |

RF Exposure

General Statement on RF energy

Your phone contains a transmitter and a receiver. When it is ON, it receives and transmits RF energy. When you communicate with your phone, the system handling your call controls the power level at which your phone transmits.

Specific Absorption Rate (SAR)

Your mobile device is a radio transmitter and receiver. It is designed not to exceed the limits for exposure to radio waves recommended by international guidelines. These guidelines were developed by the independent scientific organisation ICNIRP and include safety margins designed to assure the protection of all persons, regardless of age and health.

The guidelines use a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit for mobile devices is 2 W/kg and the highest SAR value for this device when tested at the ear was 0.847 W/kg and when tested near the body (at a distance of 15mm) the highest SAR value was 0.794 W/kg. As mobile devices offer a range of functions, they can be used in other positions, such as on the body as described in this user guide.

As SAR is measured utilising the device's highest transmitting power, the actual SAR of this device while operating is typically below that indicated above. This is due to automatic changes to the power level of the device to ensure it only uses the minimum power required to communicate with the network.

Body worn operation

Important safety information regarding radiofrequency radiation (RF) exposure.

To ensure compliance with RF exposure guidelines the phone must be used with a minimum of 15 mm separation from the body.

Failure to observe these instructions could result in your RF exposure exceeding the relevant guideline limits.

Limiting exposure to radio frequency (RF) fields

For individuals concerned about limiting their exposure to RF fields, the World Health Organisation (WHO) provides the following advice:

Precautionary measures: Present scientific information does not indicate the need for any special precautions for the use of mobile phones. If individuals are concerned, they might choose to limit their own or their children's RF exposure by limiting the length of calls, or using 'hands-free' devices to keep mobile phones away from the head and body.

Further information on this subject can be obtained from the WHO home page <http://www.who.int/peh-emf> WHO Fact sheet 193: June 2000.

Regulatory information

The following approvals and notices apply in specific regions as noted.

C € 0700

Declaration of Conformity

Yulong Computer Telecommunication Scientific (Shenzhen) Co., Ltd

Date: May 29, 2014

Declaration of Conformity

We, Yulong Computer Telecommunication Scientific (Shenzhen) Co., Ltd.

Address: Coolpad Information Harbor, 2nd Mengxi Road, Northern Part of Science & Technology Park, Nanshan district, Shenzhen, P.R.China

Declare under our own responsibility that the product:

Model: 889N

Intended use: mobile phone

Complies with the essential requirements of Article 3 of the R&TTE 1999/5/EC Directive, if used for its intended use and that the following standards have been applied:

1. Health (Article 3.1(a) of the R&TTE Directive)

- EN 62111:2008/EN62209-2:2010
- EN 50360:2001+A1:2012
- EN 62479:2010
- EN 50566:2013
- EN 62209-1:2008
- EN 50364:2010

2. Safety (Article 3.1(a) of the R&TTE Directive)

- Applied Standard(s):
- EN 60950-1:2006+A11:2009+A12:2010+A13:2011
 - EN 50332-1:2000
 - EN 50332-2:2003

3. Electromagnetic compatibility (Article 3.1 (b) of the R&TTE Directive)

- Applied Standard(s):
- EN 301 489-1 V1.9.2+3 V1.6.1+7 V1.3.1+17 V2.2.1+24 V1.5.1

4. Radio frequency spectrum usage (Article 3.2 of the R&TTE Directive)

- Applied Standard(s):
- EN 300 328 V1.3.1
 - EN 301 511 V9.0.2
 - EN 301 908-1 V6.2.1
 - EN 301 908-2 V5.4.1
 - EN 300440-1 V1.6.1
 - EN 300440-2 V1.4.1
 - EN 302 291-1 V1.1.1
 - EN 302 291-2 V1.1.1
 - EN 301908-13 V5.2.1

5. EMC Directive 2004/108/EC

- EN 55022:2008/AC:2011
- EN 55024:2010
- EN 61000-5-2:2006+A1:2009+A2:2010
- EN 61000-3-3:2008

All the reports of the applied standards have the Positive Opinion of Notified Body:


PHOENIX TESTLAB, Kühnlgswinkel 10 D-32825 Blomberg, Germany

Identification mark: **0700** (Notified Body) **CE** **CE 0700**

The technical documentation relevant to the above equipment will be held at:

Yulong Computer Telecommunication Scientific (Shenzhen) Co., Ltd

Authorized Person:



pichangyi

Distraction

Driving

Full attention must be given to driving at all times in order to reduce the risk of an accident. Using a phone while driving (even with a hands-free kit) causes distraction and can lead to an accident. You must comply with local laws and regulations restricting the use of wireless devices while driving.

Operating machinery

Full attention must be given to operating the machinery in order to reduce the risk of an accident.

Product Handling

General Statement on handling and use

You alone are responsible for how you use your phone and any consequences of its use.

You must always switch off your phone wherever the use of a phone is prohibited. Use of your phone is subject to safety measures designed to protect users and their environment.

- Always treat your phone and its accessories with care and keep it in a clean and dust-free place.
- Do not expose your phone or its accessories to open flames or lit tobacco products.
- Do not expose your phone or its accessories to liquid, moisture or high humidity.
- Do not drop, throw or try to bend your phone or its accessories.
- Do not use harsh chemicals, cleaning solvents, or aerosols to clean the device or its accessories.
- Do not paint your phone or its accessories.
- Do not attempt to disassemble your phone or its accessories, only authorised personnel must do so.
- Do not expose your phone or its accessories to extreme temperatures, minimum 0 and maximum +45 degrees Celsius.

- Please check local regulations for disposal of electronic products.
- Do not carry your phone in your back pocket as it could break when you sit down.

Small Children

Do not leave your phone and its accessories within the reach of small children or allow them to play with it.

They could hurt themselves or others, or could accidentally damage the phone.

Your phone contains small parts with sharp edges that may cause an injury or which could become detached and create a choking hazard.

Demagnetisation

To avoid the risk of demagnetisation, do not allow electronic devices or magnetic media close to your phone for a long time.

Electrostatic discharge (ESD)

Do not touch the SIM card's metal connectors.

Power supply

Do not connect your device to the power supply or switch it on until instructed to do so in the installation instructions.

Antenna

Do not touch the antenna unnecessarily.

Normal use position

When placing or receiving a phone call, hold your phone to your ear, with the bottom towards your mouth or as you would a fixed line phone.



Air Bags

Do not place a phone in the area over an air bag or in the air bag deployment area.

Store the phone safely before driving your vehicle.

Seizures/Blackouts

This phone is capable of producing bright flashing lights.

Repetitive Motion Injuries

To minimise the risk of RSI, when Texting or playing games with your phone:

- Do not grip the phone too tightly.
- Press the buttons lightly.
- Make use of the special features in the handset which minimise the number of buttons which have to be pressed, such as message templates and predictive text.
- Take lots of breaks to stretch and relax.

Emergency Calls

This phone, like any wireless phone, operates using radio signals, which cannot guarantee connection in all conditions. Therefore, you must never rely solely on any wireless phone for emergency communications.

Loud Noise

This phone is capable of producing loud noises which may damage your hearing. Prolonged exposure to music at full volume on the music player may damage the listener's hearing. Use the recommended headphones only.



PROTECT YOUR HEARING

To prevent possible hearing damage, do not listen at high volume levels for long periods. Exercise caution when holding your device near your ear while the loudspeaker is in use.

Bright Light

This phone is capable of producing flash of light or use as a torch, do not use it too close to the eyes.

Phone Heating

Your phone may become warm during charging and during normal use.

Electrical Safety

Accessories

Use only approved accessories.

Do not connect with incompatible products or accessories.

Take care not to touch or allow metal objects, such as coins or key rings, to contact or short-circuit the battery terminals.

Connection to a Car

Seek professional advice when connecting a phone interface to the vehicle electrical system.

Faulty and Damaged Products

Do not attempt to disassemble the phone or its accessory.

Only qualified personnel must service or repair the phone or its accessory.

If your phone or its accessory has been submerged in water, punctured, or subjected to a severe fall, do not use it until you have taken it to be checked at an authorised service centre.

Battery Handling & Safety

Always switch the device off and disconnect the charger before removing the battery.

Only use the battery and charger supplied, or manufacturer approved replacements intended for use with your phone. Using other batteries and chargers could be dangerous.

Do not disassemble or short-circuit the battery. Accidental short-circuiting can occur if a metallic object such as a key, paper clip, or pen touches the terminals of the battery.

Improper battery use may result in a fire, explosion, or other hazard. If you believe the battery has been damaged, do not use it, take it to a service centre for testing.

Interference

General statement on interference

Care must be taken when using the phone in close proximity to personal medical devices, such as pacemakers and hearing aids.

Pacemakers

Pacemaker manufacturers recommend that a minimum separation of 15 cm be maintained between a mobile phone and a pacemaker to avoid potential interference with the pacemaker. To achieve this use the phone on

the opposite ear to your pacemaker and do not carry it in a breast pocket.

Hearing Aids

People with hearing aids or other cochlear implants may experience interfering noises when using wireless devices or when one is nearby.

The level of interference will depend on the type of hearing device and the distance from the interference source, increasing the separation between them may reduce the interference. You may also consult your hearing aid manufacturer to discuss alternatives.

Medical devices

Please consult your doctor and the device manufacturer to determine if operation of your phone may interfere with the operation of your medical device.

Hospitals

Switch off your wireless device when requested to do so in hospitals, clinics or health care facilities. These requests are designed to prevent possible interference with sensitive medical equipment.

Aircraft

Switch off your wireless device whenever you are instructed to do so by airport or airline staff.

Consult the airline staff about the use of wireless devices on board the aircraft, if your device offers a 'flight mode' this must be enabled prior to boarding an aircraft.

Interference in cars

Please note that because of possible interference to electronic equipment, some vehicle manufacturers forbid the use of mobile phones in their vehicles unless a hands-free kit with an external antenna is included in the installation.

Explosive environments

Petrol stations and explosive atmospheres

In locations with potentially explosive atmospheres, obey all posted signs to turn off wireless devices such as your phone or other radio equipment.

Areas with potentially explosive atmospheres include fuelling areas, below decks on boats, fuel or chemical transfer or storage facilities, areas where the air contains chemicals or particles, such as grain, dust, or metal powders.

Blasting Caps and Areas

Turn off your mobile phone or wireless device when in a blasting area or in areas posted turn off “two-way radios” or “electronic devices” to avoid interfering with blasting operations.

Protection against theft

Your telephone is identified by an IMEI (phone serial number) shown on the packaging label and in the product’s memory. We recommend that you note the number the first time you use your telephone by entering *#06# and keep it in a safe place. It may be requested by the police or your operator if your telephone is stolen. This number allows your mobile telephone to be blocked preventing a third person from using it, even with a different SIM card.

Recycling information



This symbol on your telephone, the battery and the accessories means that these products must be taken to collection points at the end of their life:

- Municipal waste disposal centres with specific bins for these items of equipment
- Collection bins at points of sale.

They will then be recycled, preventing substances being disposed of in the environment, so that their components can be reused.

In European Union countries:

These collection points are accessible free of charge. All products with this sign must be brought to these collection points.

In non European Union jurisdictions:

Items of equipment with this symbol are not to be thrown into ordinary bins if your jurisdiction or your region has suitable recycling and collection facilities; instead they are to be taken to collection points for them to be recycled.

CAUTION: RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

FCC Regulations

- This mobile phone complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
- This mobile phone has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off

and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- a) Reorient or relocate the receiving antenna.
- b) Increase the separation between the equipment and receiver.
- c) Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- d) Consult the dealer or an experienced radio/TV technician for help.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

- The antenna(s) used for this transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

RF Exposure Information (SAR)

This phone is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the United States.

During SAR testing, this device was set to transmit at its highest certified power level in all tested frequency bands, and placed in positions that simulate RF exposure in usage against the head with no separation, and near the body with the separation of 10 mm. Although the SAR is determined at the highest certified power level, the actual SAR level of the device while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output.

The exposure standard for wireless devices employing a unit of measurement is known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6W/kg for an uncontrolled environment.

Tests for SAR are conducted using standard operating positions accepted by the FCC with the device transmitting at its highest certified power level in all tested frequency bands.

The FCC has granted an Equipment Authorization for this model phone with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines.

SAR information on this model phone:

| | | |
|----------------------|----------------------|-----------|
| FCC ID: R38YL889N | Highest SAR for head | 0.45 W/kg |
| | Highest SAR for body | 1.32 W/kg |

While there may be differences between the SAR levels of various phones and at various positions, they all meet the government requirements.

SAR compliance for body-worn operation is based on a separation distance of 10 mm between the unit and the human body. Carry this device at least 10 mm away from your body to ensure RF exposure level compliant or lower to the reported level. To support body-worn operation, choose the belt clips or holsters, which do not contain metallic components, to maintain a separation of 10 mm between this device and your body. RF exposure compliance with any body-worn accessory, which contains metal, was not tested and certified, and use such body-worn accessory should be avoided.

Licences



Some services and apps may not be available in all countries.

Please ask in-store for details.

Android, Google, Google Play and other marks are trademarks of Google Inc.

©Vodafone Group 2014. Vodafone and the Vodafone logos are trade marks of Vodafone Group. Any product or company names mentioned herein may be the trade marks of their respective owners.

Notice

The information in this manual is subject to change without notice. Every effort has been made in the preparation of this manual to ensure accuracy of the contents, but all statements, information, and recommendations in this manual do not constitute a warranty of any kind, expressed or implied. Read the safety precautions and safety information carefully to ensure that you use this wireless device in a correct and safe manner.

Yulong Computer Telecommunication Scientific
(Shenzhen) Co., Ltd.

Address:

Coolpad Information Harbor, 2nd Mengxi Road, Northern
Part of Science&Technology Park, Nanshan district,
Shenzhen, P.R.China

Telephone warranty

WARRANTY TERMS AND CONDITIONS

1. Vodafone undertakes the warranty of this Mobile Phone for a period of two (2) years from the date of Purchase by the original owner (not transferable) under normal use.
2. The Battery has a limited warranty for twelve (12) months, and Charger for twenty-four (24) months against manufacturing defects. Other accessories have a limited warranty for twenty-four (24) months against manufacturing defects.
3. This Warranty does not cover damage resulting from:
 - a) Normal wear & tear of the equipment;
 - b) Defects and damages due to the equipment being used other than its normal and customary manner;
 - c) An unauthorized disassembly, repair, alteration or modification being carried out;
 - d) Misuse, abuse, negligence or accident howsoever caused;
 - e) Defects or damage arising from improper testing, operation, maintenance, installation, or any alteration or modification;
 - f) Defects or damage due to spillage of food or liquids, corrosion, rust or the use of wrong voltage;
 - g) Scratches or damage to plastic surfaces and all other externally exposed parts that are due to normal customer use;
4. The Handset requiring service/repair must be delivered at the user's cost.
5. This warranty will be null and void in any of the following events:
 - a) If the serial number or warranty seal on the equipment has been defaced or removed.
 - b) If any term contained in this warranty has been altered or modified in any way without prior written consent of Vodafone.

6. The limited warranty extends only to customer who purchase the product in one of the countries (or areas) set forth at the end of this document. The limited warranty is only valid in Vodafone's intended country (or area) of sale of the Product.
7. If the product is returned to Vodafone after the expiration of the warranty period, Vodafone's normal service policies shall apply and the Consumer will be charged accordingly.
 - a) Vodafone neither assumes for it any other obligation or liability beyond that which is expressly provided for in this limited warranty.
 - b) All warranty information, product features and specifications are subject to change without notice.
8. THIS WARRANTY IS IN LIEU OF ANY AND OTHER WARRANTIES EXPRESSED OR IMPLIED, SPECIFICALLY INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. VODAFONE ASSUMES NO LIABILITY FOR THE BREACH OF THE WARRANTY BEYOND CORRECTING THE BREACH IN THE MANNER DESCRIBED ABOVE. IN NO EVENT SHALL VODAFONE BE LIABLE FOR CONSEQUENCES.

Technical data

| Basic specifications | | |
|----------------------|---|--|
| Processor | Qualcomm MSM8926 | |
| Platform | Android 4.4.2 | |
| Dimensions | 134 × 67.5 × 10.4 mm | |
| Form factor | Bar | |
| Antenna | Internal | |
| SIM card | Micro-SIM | |
| Network | GSM (900/1800/1900MHz) WCDMA (900/2100MHz) LTE (800/1800/2600MHz) | |
| WLAN | 2.4 GHz | |
| Camera | Front 0.3M pixel + Rear 5M pixel AF | |
| Headset connector | Φ3.5mm CTIA standard | |
| Screen parameters | | |
| Type | Dimensions | Resolution |
| LCD, FWVGA | 4.5-inch | 480×854 |
| Accessories | | |
| Battery | Battery name | Lithium-ion polymer rechargeable battery |
| | Rated capacity | 1,880 mAh |
| | Nominal voltage | 3.7 V |

Accessories

| No. | Name | Quantity |
|-----|--|----------|
| 1 | Phone | 1 |
| 2 | Battery | 1 |
| 3 | Travel charger | 1 |
| 4 | USB charge/data cable | 1 |
| 5 | Headset | 1 |
| 6 | Quick start guide | 1 |
| 7 | Safety & warranty information | 1 |
| 8 | NFC TAG guide with 2 TAGs (This is only available in some countries/areas) | 1 |

Note: Accessories included are dependent on the final seller. Contact the retailer for details.